

September Presentation

Alexander Papiez

Friday 16th September, 2016

- 1 Introduction
- 2 Recap: the ion exchange experiment
- 3 Ion exchange data

Introduction



Last time we met the following objectives were stated:

Goal	Status
Basic ion exchange experiments for complex quats	Achieved
Temperature vs diffusion coefficient studies	Achieved (mostly)
Polymer film studies	In progress
Provision of acrylamide beads to IP	In progress

- Ion exchange studies themselves are now essentially complete, though NMR analysis has been delayed
- Polymer film studies are ongoing, and provision of acrylamide beads to IP will be done as soon as time permits


Recap: the ion exchange experiment

- The ion exchange experiment can be summarized as follows



0.2em 0.1ptWe opt to measure the contents of the ion exchange resinWe can measure the sodium ion content (flame photometry) or quaternary ammonium ion content (qNMR spectroscopy)

Particle size analysis




Model fitting

We now examine which model best fits the ion exchange data


Model Author	Model expression
Boyd (Sphere)	$F = 1 - \frac{6}{\pi^2} \sum_{n=1}^{\infty} \frac{1}{n^2} e^{-D_i \pi^2 n^2 t r^{-2}}$
Boyd (Slab)	$F = 1 - \frac{8}{\pi^2} \sum_{n=1}^{\infty} \frac{1}{(2n-1)^2} e^{-(2n-1)^2 \pi^2 D_i t 4r^{-2}}$
Diffusion in a bounding film	$\log(1 - F) = \frac{(\frac{3D_i}{r_0(\Delta r_0)^\kappa})}{2.303} t$
Hellferich	$F(t) = \sqrt{1 - e^{\pi^2 f_1(\alpha)t + f_2(\alpha)t^2 + f_3(\alpha)t^3}}$




Flame Photometer Calibration Curve



F vs T for 20 degrees



F vs T for 30 degrees



F vs T for 40 degrees

